# Products Care & Maintenance



AKUART®

CANVAS / TEXTILES

/ Regularly dust with a soft brush or vacuum to prevent dirt accumulation.
/ Treat stains on the canvas promptly to prevent them from setting. Absorb excess liquid immediately.
/ Use antibacterial wipes or sprays to disinfect, always following the manufacturer's instructions.
/ Machine washing is applicable only for the detachable Supersonic Canvas. Remove the canvas carefully using the AKUART hand tag. The Canvas is washable at temperatures up to 60°C. Ensure it is completely dry before remounting. Circularity and material recovery: Recycle as textile (100% polyester). Consider refurbish (Akuart service)

ALUMINIUM FRAMES

/ Regularly clean with a soft brush or vacuum to prevent dirt from accumulating.
/ Disinfect using antibacterial wipes or sprays, ensuring you follow the manufacturer's instructions. Circularity and material recovery: recycle as metal (100% recycled aluminium). Consider repair/spare parts (Akuart service)

WOODEN FRAMES

/ Regularly clean using a soft brush or vacuum to prevent the build-up of dirt. Circularity and material recovery: recycle as wood (100% solid wood). Consider repair (Akuart service)

WRITING BOARDS

/ Regularly clean using a soft brush or vacuum to prevent dirt build-up.
/ Steam Cleaning: Ensure you follow the appropriate instructions and safety guidelines.
/ Disinfect with antibacterial wipes or sprays, always adhering to the manufacturer's instructions. Circularity and material recovery: recycle as metal (ceramic on steel). Consider replacement (Akuart service)



AKUART